


Overview: Module Block Diagram



NOMINAL)

THE INFORMATION CONTAINED ON THIS DRAWING IS PROPRIETARY AND CONFIDENTIAL TO MARLIN TECHNOLOGIES INC. UNAUTHORIZED USE OR DISTRIBUTION WITHOUT CONSENT IS PROHIBITED.

UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES AND TOLERANCES ARE TWO PLACE THREE PLACE **ANGLES**

DECIMAL +/- 0.05

DECIMAL +/- 0.020

DO NOT SCALE DRAWING

CHECKED J. COOPER DATE 06/27/23 APPROVED J. COOPER DATE 06/27/23 MARLIN TECHNOLOGIES INC.

OUTLINE, 505030 MFLEX 8IN/8OUT CAN MODULE

DRAWING NUMBER SIZE TYPE REV

013946 DATE 02/07/22


DRAWN M. PETZKE

SHEET 2 OF 3


Overview: Input/Output Configurations

REVISIONS								
REV	DATE	ECN	DESCRIPTION	APVD				
Α	12/17/21	13944E	RELEASE TO PRODUCTION	JC				


(* NOTE: Analog Input Circuit and Best Practices)



- Generated Analog Signal
- Analog Potentiometer (5k or less)
- On/Off Switch to Power (No Pull-Down)
- On/Off Switch to Gnd (No Pull-Up)
- 3-way Switch to Pwr/Gnd (No PU/PD)
- Frequency Input (0-5V, LS Output)
- PWM Duty Cycle (0-5V, LS Output)
- Quadrature Input (0-5V, LS Output)





(* NOTE: Resistance Input Circuit and Best Practices)



- An improper resistor connection is likely to damage the module.

(* NOTE: Current Input Circuit and Best Practices)





- Voltage on the input Pin must not exceed 6V when configured for current input.
- The input Pin when configured for current sensing is current sink and must be wired as such. Improper wiring can damage the module.

Input/Output Configuration Options

Input Type	#1	#2	#3	#4	#5	#6	#7	#8
Digital Active High - Thres	•	•	•	•	•	•	•	•
Digital Active Low - Thres	•	•	•	•	•	•	•	•
Analog 0-36V	•	•	•	•	•	•	•	•
Frequency	•	•	•	•				
PWM Duty Cycle	•	•	•	•				
Resistance	•	•	•	•				
Current (0-20mA)	•	•	•	•				
Quadrature – X1	•*	•*	•*	•*	•*	•*	•*	
Quadrature – X2	•*	•*	•*	•*	•*	•*	•*	
Quadrature – X4	•*	•*	•*	•*	•*	•*	•*	
Quadrature – B		•	•	•	•	•	•	•

*When configured as Quadrature, The next adjacent input is automatically configured as the channel B input. (i.e. If In1 = QuadX , then In2 = Quad Channel B)

Output Type	#1	#2	#3	#4	#5	#6	#7	#8
00 - Disabled	•	•	•	•	•	•	•	•
01 – Active HI Digital	•	•	•	•	•	•	•	•
02 – Active LO Digital	•	•	•	•	•	•	•	•
03 – HS PWM Closed Loop	•	•	•	•	•	•	•	•
04 – HS PWM Open Loop	•	•	•	•	•	•	•	•
03 – LS PWM Closed Loop	•	•	•	•	•	•	•	•
04 – LS PWM Open Loop	•	•	•	•	•	•	•	•

In/Out Tolerances (@25C)							
Analog Input	+/-50mV						
Resistance Input	+/-2%						
Current Input (0-20mA)	+/-50uA						
Current Control Output	+/-50mA						

UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES AND TOLERANCES ARE

TWO PLACE THREE PLACE DECIMAL DECIMAL +/- 0.05 +/- 0.020

ANGLES

+/-

DO NOT SCALE DRAWING

CHECKED J. COOPER DATE 06/27/23 MARLIN TECHNOLOGIES INC.

OUTLINE, 505030 MFLEX 8IN/8OUT CAN MODULE

DRAWING NUMBER SIZE В 013946

TYPE **REV**

APPROVED J. COOPER DATE 06/27/23 DRAWN M. PETZKE

DATE 02/07/22 SHEET 3 OF 3

THE INFORMATION CONTAINED ON THIS DRAWING IS PROPRIETARY AND CONFIDENTIAL TO MARLIN TECHNOLOGIES INC. UNAUTHORIZED USE OR DISTRIBUTION WITHOUT CONSENT IS PROHIBITED.